



# **COBRA BRAKE INSTALLATION MANUAL**

Techtop Industries, Inc.  
2815 Colonnades Court  
Peachtree Corners, GA 30071

1-855-TECHTOP  
1-855-832-4867  
fax: 1-866-204-1498

info@techttopind.com  
www.techttopind.com





# Table of Contents



## 1. Working Principals

## 2. Installation

### 2.1 Installation

### 2.2 Tools Needed

### 2.3 Brake Components

### 2.4 Step by Step Installation Instruction

## 3. Connection Method

## 4. Product Model

## 5. Braking Torque

## 6. Brake Operation

## 7. Brake Maintenance

### 7.1 Brake Maintenance

### 7.2 Tools Needed

### 7.3 Air Gap Adjustment

### 7.4 Brake Air Gap “Z”



## Working Principals



### **THREE-PHASE BRAKE MOTOR**

The brake motor consists of an induction, TEFC, IP55 degree of protection, class “F” (155°C) motor coupled to a spring applied electromagnetic brake.

The REACH brake is supplied with class “F” (155°C) insulation and is suitable to operate in ambient temperature ranging from 10°C to 40°C.

- 205VDC Coil
- Long service life guaranteed by using German wear-proof friction disk without lead and asbestos
- Preset air gap for convenient and efficient mounting




## INSTALLATION

The brake can be installed in any position, providing the brake is not exposed to excessive penetration of water, oil or abrasive dust.

### 2.2 TOOLS NEEDED

- 7mm wrench/nut driver
- Phillips head screw driver
- Snap ring pliers
- 5mm allen wrench (REB0410)
- 4mm allen wrench (REB0408)
- 12 mm open end wrench
- 0.8mm feeler gauge
- 0.2mm feeler gauge

### 2.3 Stator of B-Type Brake + Friction Disk Components + Splined Hub



1. Stator
2. Armature
3. Friction Disk
4. Splined Hub
6. Shaft
7. Spring
8. Hollow Screws
- Z. Air Gap



Remove motor fan cover

1




Remove circlip at end of shaft

2



Loosen fan retaining bolts and remove fan

3



Clean shaft and end-bell of any grease and debris

4



Install supplied key into shaft

5



Place friction plate against end-bell (plate mounted with lip pointing away from the end plate and towards the brake)

6



Install splined hub onto motor shaft

7



Align friction disk with splined hub


Slide onto hub against the friction plate

8



Install circlip in groove closest to splined hub


9



Remove dust cap from stator bore

Remove dust seal

10




Install brake stator evenly, tightening the retaining bolts

11



Remove all plastic spacers

12



Check friction plate and manual release handle air gap (See 7.4 - 7.5)


Adjust if necessary

13



Install stub shaft

14




Install fan and circlip

15





# Installation Instruction



Route brake cable around fan cover mounting post

**16**



Install supplied extended fan cover

**17**



Install manual release handle

**18**



Route brake cable through cable gland

Install rectifier in motor terminal box

**19**



Connect brake leads to rectifier  
(Brown +, Black -) (See Connection Method)


**20**



The bridge rectifier is connected directly to the motor terminal without any interruption.

**WARNING:** Please observe the correct power supply to the brake.

- 230/460V connect the bridge rectifier terminal to motor terminals 7 and 9.
- Independent AC Power Supply
- Connect the bridge rectifier terminals to the independent 220V or 230V source, but always through a N.O. contact that operates simultaneously with the connection of the motor supply voltage.






# Product Model



## REB04 Series Spring - applied Electromagnetic Brakes



## Braking Torque (N.m)

Frame Size	8	10	
Motor Frame	56	56H	
Rated Torque (Rotation Speed 100r/min)	6	11	Decelerating Brake
	7	14	
	8	16	Rated Braking Torque
	10	20	Holding Brake
	12	23	



## Brake Operation



REB-04 Series spring-applied single-disk electromagnetic brakes are very safe to the user. The friction disk which has two friction surfaces is mounted to the motor shaft using a splined hub and keyed to the motor shaft.

The brake is engaged when no power is supplied and disengaged when power is applied. When no power is applied, the springs press the friction disk and the friction plate.

When power is applied, the stator coil acts as an electromagnet, to pull the friction disk away from the friction plate, allowing the motor to rotate.



# Brake Maintenance



## 7.1 BRAKE MAINTENANCE

Periodic checking and adjusting of brake air gap is required, based upon user maintenance schedule. Internal cleaning may be required in the event of penetration of water or dust.

## 7.2 TOOLS NEEDED

### **REB0408**


- 4 mm allen wrench
- 10 mm low profile open end wrench
- 7 mm low profile open end wrench
- 0.8 mm feeler gauge
- 0.2 mm feeler gauge

### **REB0410**

- 5 mm allen wrench
- 12 mm low profile open end wrench
- 7 mm low profile open end wrench
- 0.8 mm feeler gauge
- 0.2 mm feeler gauge



## 7.3 AIR GAP ADJUSTMENT



Product Size	Rated Air Gap "Z" (+0.1/-0.05)(mm)	Installation Air Gap "S" (+0.1/0)(mm)	"Z" + "S" (mm)
REB0408	0.2	0.8	1
REB0410			




## 7.4 BRAKE AIR GAP “Z”

The brake air gap is preset at factory, and typically will not require additional adjustment at the time of installation. The checking of the brake gap during the installation process is a secondary check to verify the correct gap setting. As the brake is used, the air gap will need to be periodically checked and adjusted to ensure proper braking operation. To check and adjust the brake gap, follow the steps outlined below.

Ensure the power to the motor is off and follow your facilities lock out tag out procedure to prevent any unexpected starting of the motor.

**1**



Check the air gap using a 0.8mm feeler gauge referring to the picture below and brake part diagram. The acceptable air gap range is from 0.9mm to 0.8mm. If the air gap is outside the acceptable range continue to step 3 below to perform adjustment.

**2**



Loosen the brake mounting screws.

**3**

# Brake Maintenance



Adjust the brake mounting hollow screws to obtain proper air gap. Only small adjustments should be required.

4



Tighten brake mounting screws.

5



Recheck air gap next to each mounting screw to ensure even adjustment. Repeat as necessary to obtain proper air gap.

6





# Brake Maintenance



## 7.5 RELEASE HANDLE AIR GAP “S”

With Power Off, check air gap “S”. If adjustment is needed, adjust using the release handle installation screws. Ensure the gap is the same on both sides.

Ensure the power to the motor is off and follow your facilities lock out tag out procedure to prevent any unexpected starting of the motor.

1



Check release handle air gap at position “S”.

2



If adjustment is needed, adjust using the release handle installation screws

Ensure the gap is the same on both sides

3



# Brake Maintenance Schedule



Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_

Date: \_\_\_\_\_ Inspector: \_\_\_\_\_

Airgap Z: \_\_\_\_\_ Airgap S: \_\_\_\_\_



For any additional questions  
Contact Customer Service:

Techtop Industries, Inc.  
2815 Colonnades Court  
Peachtree Corners, GA 30071

1-855-TECHTOP  
1-855-832-4867  
fax: 1-866-204-1498

[info@techtopynd.com](mailto:info@techtopynd.com)  
[www.techtopynd.com](http://www.techtopynd.com)

